



NOTES

There may be errors in this drawing!

Some values differ from what's printed on the PCB.
 These are the parts actually mounted in my VL-1.

LA4140 -> LA4142
 LA6358 -> LA6355
 2SC1815 -> 2SC1740
 2SA715 -> 2SB698
 S2K30 -> 2SK246

Component references are completely arbitrary.
 You have to figure out the digital board yourself.

Casio VL-Tone (VL-1) analog board		VL-1	6
Clemens Valens		Sheet: 1/1	1.0
		27/05/2010 16:43:41	

This is drawn as a stereo jack,
but it is of course mono.